

Servo Type 140 Power Feed

ORDERING INSTRUCTIONS

1. Please specify the type, model number, and serial number of the unit for which parts are being ordered.
2. The limit switch bracket, limit switch assembly, and bevel gear are determined by model number.
3. Note that parts are listed by assembly. They may be ordered as complete assemblies or as individual parts.

REPAIRS

For repairs, contact Servo Products Company for the location of your authorized Service Center or see our website.

Qty	Part No.	Description
Replace as unit - components permanently potted in a molded plastic case		
1	2023-10	Limit Switch Assembly - 6 Foot cord
Unit obsoleted 7/02 (cast metal box) - interchangeable with new design		
1	2023-10	Limit Switch Assembly - 6 Foot cord
2	01241	Micro switch, 41-SM1-T2 (Honeywell)
1	0266	Gasket
2	1469	Plunger
2	1557	Switch actuator
1	57425	Limit switch cable, 6 ft.
1	6037	Spring
Parts will continue to be available from Servo until sold out. Call Servo for sources.		

REPAIR POLICY

These conditions must be met for an authorized service center to accept returned goods from customers for in-warranty or out-warranty repairs.

1. The freight must be prepaid on all products sent to an authorized service center for warranty repair. The service center will pay the return freight on all products under warranty. The service center will repair or replace, at their own option, products which prove to be defective during the warranty period.

2. The freight will be paid by the customer both ways on products which are not under warranty and the repaired item will be returned C.O.D.

Contact Servo Products Company for the location of authorized service centers or see our website.

WARRANTY

All Servo Products Company products are warranted against defects in material and workmanship. This warranty applies for one year from the day of delivery to the customer. We will repair or replace at our own option products which prove to be defective during the warranty period, provided they are returned to Servo Products Company, freight prepaid. This guarantee does not include repair or replacement required because of misuse, abuse or normal wear and tear. Repairs made by other than the factory or an authorized service center terminate Servo Products Company's liability under this guarantee. This guarantee is made expressly in place of all other guarantees or warranties, expressed or implied, with respect to quality, merchantability, or fitness for a particular purpose.

SERVO PRODUCTS COMPANY

34940 Lakeland Blvd.

Eastlake, OH U.S.A. 44095

Phone: 440-942-9999 or 800-521-7359; Fax: 440-942-9100

www.servoproductsco.com Email: info@servoproductsco.com

PARTS LIST

Qty	Part No.	Description
1	5085	Potentiometer Assembly
1	00541	Potentiometer, 500 ohm, 2-3/4" shaft
3	02258	Terminal pin, small
1	02260	Connector housing, 4 pin
1	04995	3/8" Washer, internal tooth, small
1	4897	Potentiometer bracket
1	5104	Potentiometer pilot
1	5091-2	Reversing Switch Assembly
1	01294	MOV, 130 volt, 10 amp
2	01851	Pin
1	02526	Terminal pin, large
2	03033	4-40 x 1-1/8" Phillips pan head screw
2	03035	Micro switch, type V3, 15 amp
1	03094	Receptacle, male, 2 pin small
2	03598	4-40 hex lock nut, nylon
1	4893	Switch pedestal
1	5092	Rapid Switch Assembly
2	00717	4-40 x 5/8" Phillips pan head screw
2	02526	Terminal pin, large
1	03035	Micro switch, type V3, 15 amp
2	03598	4-40 hex lock nut, nylon
1	4895	Rapid switch bracket
1	4913	Lift Fork Assembly (includes Lower Drive Shaft)
2	00564	Roll pin 1/8 x 5/8"
1	01220	Fiber washer
1	01334	Needle bearing
2	01335	Bearing race
1	01809	Steel dowel 1/8 x 1/2"
1	1344	Spring, lower drive shaft
1	3457	Clutch
1	4908	Bearing cup
1	4909	Support lifter sleeve
1	4912	Lower drive shaft
1	4988	Cam follower
1	4989	Lift fork
1	4737	Zytel Gear & Hub Assembly
1	01061	Washer
2	02885	Spring washer
1	02886	Tru-arc retaining ring
1	02887	Thrust washer
1	4734	Gear hub
1	4735	Helical gear (without hub)

Servo Products Company reserves the right to make changes without notice or obligation in prices, specifications, or models.